

Dräger PARAT 3200 Donning Poster



Grasp tab and pull.



Remove the sealing band.




Open the housing.



Take out the unit.



Place the mouthpiece in your mouth, holding it in place with your teeth, and your lips around it. Pull the nose clip to open.



Position the nose clip on your nose so that it closes your nostrils. Leave the contaminated area immediately.

Dräger PARAT 3200 Anlegeposter



Plombe mit der Lasche aufreißen.



Verschlussband entfernen.




Verpackung Öffnen.



Gerät entnehmen.



Mundstück in den Mund stecken und mit den Lippen umschließen. Die Beißzapfen mit den Zähnen halten. Die Nasenklemme auseinanderziehen.



Die Nasenklemme auf die Nasenflügel setzen und unverzüglich aus dem Gefahrenbereich flüchten.